



## Car: Cruze

### \*Accessories

- Accessories

### \*Air Bag

- Air Bag Sensor
- Air Bag

### \*Air Conditioner

- A/C & Heater Control Asm
- A/C & Heater Module Arm (rhd)
- A/C & Air Distribution System (rhd)
- A/C Compressor – diesel (llw/2.0r)
- A/C Control System Sensor
- Diesel - A/C Refrigeration System (llw/2.0r)
- Diesel Heater – Hoses & Pipes

### \*Air Intake

- Diesel – Low Pressure (llw/2.0r)
- Diesel – High Pressure (llw/2.0r)

### \*Alternator

- Diesel

### \*Antenna

- Rr Window (u77, Hal)

## \*Audio

-Audio System

-Speaker

## \*Axle Front

-Diesel At

-Diesel Mt

## \*Battery

- Diesel

## \*Belt

- Diesel

## \*Body

- Insulator

-Moulding

-Ornamentation

-Plug

## \*Body Parts

-Engine Compartment

-Rear End

-Roof

-Side Frame

-Underbody

## \*Body Shell

-Body Shell

## \*Brakes

-Abs Lines

- Electrical System

- Pedal & Master Cylinder Mounting

- Pedal & Master Cylinder Mounting Automatic Transmission (mh7, mh8, rhd)

- Pressure Modulator Valve

#### \*Brakes

- Booster & Master Cylinder Mounting (llw/2.0r) (rhd)

- Caliper / front 16" (j60)

- Caliper / rear 16" (j60)

- Lines Rear Disk (j60, j67)

- Parking Brake System Disk (j60, j67)

- Rotor

#### \*Bumper

- Front

- Front Mounting

- Rear

#### \*Clutch

- Diesel

- Diesel – Pedal Cylinder & Fixings (rhd, mfv)

#### \*Door

- Front Hardware

- Front Panel & Trim

- Rear Hardware

- Rear Panel & Trim

- Window Regulator - Front

-Window Regulator - Rear

#### \*Control Arm

-Control Arm

#### \*Engine Diesel

-Assembly

-Cylinder Parts & Internal Parts (llw/2.0r)

-Cylinder Head & Related Parts (llw/2.0r)

-Engine Cover (llw/2.0r)

-Exhaust System Part 1 Front (llw / 2.0r)

-Exhaust System Part 2 Front (llw / 2.0r)

-Exhaust System Part 3 Center & Rear (llw / 2.0r)

-Mountings - Automatic

-Mountings - Manual

-Oil Pan & Filter (llw / 2.0r)

-Oil Pump & Fittings (llw / 2.0r)

-Timing Belts, Gears & Pulleys (llw / 2.0r)

#### \*Fendor

-Front End

#### \*Fuel System - Diesel

- Fuel Injector Rail (llw / 2.0r)

- Fuel Supply System Center / rear (llw / 2.0r)

- Fuel Supply System – Front (llw / 2.0r)

-Fuel Tank Mounting (llw / 2.0r)

#### \*Fuse & Relay

- Engine Compartment

- Instrument Compartment

- \*Hood

- Hood & Ornament

- \*Horn

- \*Instrument Panel

- Cluster

- Part 1

- Part 2

- \*Lamp

- Front

- Rear

- \*Lock

- Cylinder Set

- Keyless Remote

- \*Mirrors

- \*Module

- Bcm

- Diesel Ecm

- \*Radiator

- Diesel – Hoses & Pipes

- Diesel – Radiator & Engine Coolant Fan (Ilw/2.0r)

- Grille

- \*Rear Axle

- Diesel

### \*Reverse Sensor

- Sensor System / rear Object (ud7)

### \*Roof

- Hardware / sliding sunroof (cf5)
- Hardware / sliding sunroof mount (cf5)
- Headliner with sunroof
- Headliner without sunroof

### \*Seat

- Co Driver – Seat Parts
- Co Driver Asm
- Driver Asm
- Driver Seat Parts
- Rear Back (a62) Fixed Type
- Rear Back (a64) Folding Type (40%)
- Rear Back (a64) Folding Type (60%) (exe Aqp)
- Rear Cush (a62) Fixed Type
- Rear Cush (a64) Folding Type

### \*Seat Belt

- Front Seat Belt
- Rear Seat Belt

### \*Spare Wheel & Jack

### \*Starter Motor

- Diesel – Motor Mounting (llw / 2.0r)
- Starter – Diesel

### \*Steering

- Diesel – Pump Mounting (llw / 2.0r)
- Diesel - Steering Pump Lines (llw / 2.0r) (rhd)
- Steering Column Cover & Switch
- Steering Column Part 1
- Steering Gear Asm (rhd)
- Wheel & Horn Parts

#### \*Suspension

- Front
- Front Strut Asm
- Rear

#### \*Tail Gate

- Hardware

#### \*Transaxle – Diesel

- Maindrive Pinion Gears (mfv)
- Mainshaft Gears (mfv)
- Selector Shaft and Fork (mfv)
- Transmission Assembly (mfv)
- Transmission Case & Covers (mfv)
- Transmission Shift Control D33 (mfv)

#### \*Transaxle At – Diesel

- Associated Parts & Torque Converter (mh7,m8)
- Case (mh7,m8)
- Clutch (mh7,m8)
- Control Valve Body (mh7,m8)
- Control Valve Bodyii (mh7,m8)

- Converter
- Drive Link A (mh7,m8)
- Front Differential Carrier (mh7,m8)
- Input, Output & Reaction Gears (mh7,m8)
- Low & reverse & clutch Plate (mh7,m8)
- Oil Pump (mh7,m8)
- Park System (mh7,m8)
- Reverse Clutch (mh7,m8)
- Shift Control (mh7,m8)
- Torque Converter & Fluid Pump Housing (mh7,m8)
- Transfer Case Vent Tube (mh7,m8)
- Transmission Assembly (mh7,m8)
- Transmission Oil Cooler Pipes (mh7,m8)

#### \*Trim

- Back Window Shelf
- Center Pillar & Quarter
- Front
- Front Door
- Rear Compartment
- Rear Door

#### \*Turbocharger

- Mountings
- Oil Lines

#### \*Weatherstrip

- Front Door



- Rear Door

- \*Wheel

- Aluminium Wheel (wqs, wqx)

- Liner

- \*Window

- Quarter

- Rear

- \*Windshield

- Trim & Hardware

- \*Windshield & Wiper

- Wiper System

- \*Wiring Harness

- A/c & Heater Module Asm (rhd)

- Body

- Diesel Engine

- Front Lamps

- Ip