



## Car: Spark

### \*Accelerator

- Accelerator control

### \*Air Bag

- Air Bag System

### \*Air Conditioner

- Air Conditioner Control Switch
- Air Conditioner Hose & Pipe Line
- Blower
- Compressor
- Compressor Mount
- Condenser
- Evaporator

### \*Air Distributor

- Air Distributor

## \*Air Intake System

- Air Intake 1
- Air Intake 1i

## \*Alternator

- Alternator – 1.0L
- Alternator Mount-1.0L
- Child Part Lucas

## \*Antenna

- Antenna

## \*Axle

- Axle Shaft Parts
- Axle Shaft Unit
- Rear Axle

## \*Battery

- Battery

## \*Body Parts

- Body Shell

- Dash Panel & Cowl
- Fender Liner
- Front Door Panel
  
- Front Floor Panel
- Front Panel
- Hood Panel
  
- Rear Door Panel
- Rear Floor Panel
- Roof Panel
- Side Body Panel
- Tail Gate Panel

#### \*Brake

- Abs Module
- Anti lock Brake System
- Brake Pedal

-Brake Pipe Front-w/o Abs

-Brake Pipe Front-with Abs

-Front Brake

-Master Brake Unit-Ckd

-Master Brake Unit Child Parts-Brake India

-Master Brake Unit Child Parts-Ckd

-Parking Brake

-Parking Brake

-Rear Brake

#### \*Bumper

-Front bumper

-Rear Bumper

#### \*Canister

-Canister & Fuel Vaccum

## \*Carpet

- Floor Carpet

## \*Clutch - Diesel

- Cable Clutch

- Clutch Cover & Disc

## \*Console

- Console

## \*Emblem

- Emblem & littering

## \*Control Arm

- Control Arm

## \*Electrical

- Electrical Parts

## \*Emblem

Emblem & Lettering

## \*Emission

-Emission Module

.....

## \*Engine

-Belt System

-Cam Support & Shaft - 1.0 L

-Crankshaft & Piston - 1.0L

-Cylinder Head – 1.0 L

-Engine Asy. 1.0 L

-Engine Block – 1.0 L

-Oil Pan & Pump – 1.0L

-Repair Kit - 1.0 L

-Timing Cover – 1.0 L

## \*Exhaust

-Exhaust Pipe

## \*Frame

## \*Fuel Injection

-Fuel Injection – 1.0 L

\*Fuel Tank

-Fuel Line

-Fuel Tank

\*Fuse & Relay

\*Gear Shift

-Gear Shift Control – Manual 1.0 L

\*Glass

\*Headlining

\*Ignition

-Ignition Cable – 1.0 L

\*Instrument Panel

-Instrument Centre Parts

-Instrument Cluster

-Instrument Panel

\*Knuckle

-Front Knuckle & Hub

-Rear Knuckle & Hub

\*Lable

-Lable & Sticker

### \*Lamp

-Front Lamp

-Rear Lamp

### \*Locks

-Car Lock

-Electric Door Locks

-Front Door Lock

-Fuel Filler Locks

-Rear Door Locks

-Tail Gate Locks

### \*Lpg

-Body Parts

-Ecu

-Fuel Tank & Its Mounting

-Gas injection

-Intake Manifold – 1.0 L

-Layout, Labels & Electricals

-Layout of Lpg Parts



- Lpg Filler

- Lpg Filter

- Maintenance Parts

- Reducer & Solenoid

- Wiring Harness

#### \*Manifold

- Exhaust Manifold – 1.0 L

- Intake Manifold – 1.0 L

- Thermostat – 1.0 L

#### \*Mirror

- Out Side Mirror

#### \*Molding

- Body Side Molding

#### \*Mount

- Engine Mount

#### \*Mud Guard

#### \*Radiator

- Fan

- Radiator

-Radiator Hose & Pipe – 1.0 L

### \*Seat

-Front Seat

-Front Seat Parts

-Rear Seat Parts

-Seat Guide Rail

### \*Seat Belt

-Front Seat Belt

-Rear Seat Belt

### \*Shock Absorber

-Front Shock Absorber

-Rear Shock Absorber

### \*Spoiler

### \*Starter

### \*Steering

-Power Steering Pipe Line

-Steering Coloumn

-Steering Coloumn Cover

-Steering Gear Parts

-Steering Gear Parts – Sona

-Steering Gear Unit

-Steering Wheel

#### \*Sunshade

-Sunshade & Inside Mirror

#### \*Switch

-Molding & Switch

#### \*Tool

#### \*Trans Axle

-Differential Gear – 1.0 L

-Gear shift Cover & Fork - 1.0 L

-Manual Transaxle – 1.0 L

-Transaxle Gear – 1.0 L (1)

-Transaxle Gear – 1.0 L (2)

-Transaxle Related Parts – 1.0 L

#### \*Trim

-Front Door Trim

-Front Pillar Trim

-Rear Door Trim

-Rear Pillar Trim

-Shelf Back Panel

### \*Vaccum Hose

- Vaccum Hose – 1.0 L

### \*Weatherstrip

- Front Weatherstrip

- Rear Weatherstrip

### \*Wheel

- Wheel & Wheel Cover

### \*Window

- Front Window Lifter

- Rear Window Lifter

### \*Wiper

- Rear Wiper

- Windshield Washer

- Windshield Wiper

### \*Wiring Harness